



**5455-2**

**UNIVERSAL BOLT HOLDER**

- Used for replacing pins on clevis type hardware
- Jaw is spring loaded

CAT NO	DESCRIPTION	LBS
5455-2	UNIVERSAL BOLT HOLDER	1.5



**5455-15**

**UNIVERSAL LOCATING PIN**

- Used to align joints and holes on clevis type suspension insulators and hardware

CAT NO	DESCRIPTION	LBS
5455-15	UNIVERSAL LOCATING PIN	0.5



**5454-2**

**UNIVERSAL BALL SOCKET FORK**

- Used to align and hold ball socket fittings for removal of cotter pin

CAT NO	DESCRIPTION	LBS
5454-2	UNIVERSAL BALL SOCKET FORK	0.6



**5455-29**

**UNIVERSAL BALL SOCKET ADJUSTER**

- Used to support and align ball socket adapter between ball fitting on disc insulator and clevis fitting on suspension or strain clamp

CAT NO	DESCRIPTION	LBS
5455-29	UNIVERSAL BALL SOCKET ADJUSTER	0.9



**5454-6**

**UNIVERSAL 90 DEGREE ADAPTER**

- When mounted on universal sticks, this adapter will allow fittings to be set at almost any angle

CAT NO	DESCRIPTION	LBS
5454-6	UNIVERSAL 90 DEGREE ADAPTER	0.4



**5454-5**

**UNIVERSAL CRESCENT SKINNING KNIFE**

- Used to skin conductors before installing hot line clamps and connections
- Replaceable blades

CAT NO	DESCRIPTION	LBS
5454-5	UNIVERSAL CRESCENT SKINNING KNIFE	1.0
1-08402	REPLACEMENT BLADE	0.1