

TELESCOPIC TEL-O-POLE HOT STICK REPAIR PARTS LIST - S AND ST MODELS

TUBULAR SECTIONS										
MODEL	BASE CAP	9	8	7	6	5	4	3	2	1
S-240 ST-240	P18039	P21652	P21586	P20008	P20007	P20006	P20005	P20004	P20003	A20316 A20318
S-235 ST-235	P18037		P20013	P20008	P20007	P20006	P20005	P20004	P20003	A20316 A20318
S-230 ST-230	P18031			P20012	P20007	P20006	P20005	P20004	P20003	A20316 A20318
S-225 ST-225	P18030				P20011	P20006	P20005	P20004	P20003	A20316 A20318
S-220	P18029					P20010	P20005	P20004	P20003	A20316
S-216	P18028						P20009	P20004	P20003	A20316
S-212	P18028						P20022	P20021	P20020	A20317
COMPLETE LOCK ASSEMBLIES										
S/ST-240			A14081	A14010	A14009	A14008	A14006	A14002	A14001	A14080
S/ST-235				A14010	A14009	A14008	A14006	A14002	A14001	A14080
S/ST-230				A14079	A14009	A14008	A14006	A14002	A14001	A14080
S/ST-225					A14078	A14008	A14034	A14021	A14001	A14080
S-220						A14077	A14034	A14002	A14001	A14080
S-216							A14076	A14002	A14001	A14080
S-212							A14076	A14002	A14001	A14080
LOCK PIN & SPRING ASSEMBLIES										
S/ST-240			A12009	A12009	A12008	A12007	A12005	A12002	A12001	A12045
S/ST-235				A12009	A12008	A12007	A12005	A12002	A12001	A12045
S/ST-230					A12008	A12007	A12005	A12002	A12001	A12045
S/ST-225						A12007	A12026	A12025	A12001	A12045
S-220							A12026	A12002	A12001	A12045
S-216								A12002	A12001	A12045
S-212								A12002	A12001	A12045
P16531	ROLL PIN - USED FOR ALL MODELS									
A10434	UNIVERSAL HEAD - USED FOR ALL MODELS									
P10431	UNIVERSAL DISCONNECT HOOK - USED FOR ALL MODELS									
P16193	BASE CAP SCREWS - USE FOR MODEL S/ST-240 AND S/ST-235									
P12022	BRASS DRIVE PIN(S) FOR ALL LOCK ASSEMBLIES									

COMPLETE SET OF PIN AND SPRING ASSEMBLIES		
FOR YELLOW #1 TIP POLES	FOR GREEN #1 TIP POLES	
CAT NO	CAT NO	FOR MODEL
251	A12046	S-212
252	A12047	S-216
253	A12048	S-220
254	A12049	S/ST-225
255	A12050	S/ST-230
256	A12051	S/ST-235
-----	A12052	S/ST-240



HEAVY DUTY TEL-O-POLE HOT STICK REPAIR PARTS / SH-MODELS

COMPLETE SET OF PIN AND SPRING ASSEMBLIES	
CAT NO	FOR MODEL
258	SH-216
259	SH-220
260	SH-250
261	SH-230
280	SH-235

TUBULAR SECTIONS									
MODEL	BASE CAP	8	7	6	5	4	3	2	1
SH-235	P18039	P21721	P21586	P20008	P20007	P20006	P20005	P20004	A20329
SH-230	P18037		P20013	P20008	P20007	P20006	P20005	P20004	A20329
SH-250	P18031			P20012	P20007	P20006	P20005	P20004	A20329
SH-200	P18030				P20011	P20006	P20005	P20004	A20329
SH-216	P18029					P20010	P20005	P20004	A20328
COMPLETE LOCK ASSEMBLIES									
SH-235			A14081	A14010	A14009	A14008	A14006	A14002	A14001
SH-230				A14010	A14009	A14008	A14006	A14002	A14001
SH-250				A14079	A14009	A14008	A14006	A14002	A14001
SH-200					A14078	A14008	A14034	A14021	A14001
SH-216						A14077	A14034	A14002	A14035
LOCK PIN & SPRING ASSEMBLIES ONLY									
SH-235			A12009	A12009	A12008	A12007	A12005	A12002	A12001
SH-230				A12009	A12008	A12007	A12005	A12002	A12001
SH-250					A12008	A12007	A12005	A12002	A12001
SH-200						A12007	A12026	A12025	A12001
SH-216							A12026	A12002	A12024
P16544	ROLL PIN - ALL MODELS								
A10434	UNIVERSAL HEAD - ALL MODELS								
P10431	UNIVERSAL DISCONNECT HOOK - ALL MODELS								
P16193	SCREWS FOR BASE CAP - MODELS SH-235 AND SH-230								
P12022	BRASS DRIVE PIN(S) FOR ALL LOCK ASSEMBLIES								

