


For replacement parts, call 1-800-477-5003  
 Please have the following information ready:  
 -Model number  
 -Serial number (if any)  
 -Part description and number as shown in parts list

## Figure 5 - Base Hoist



### Parts List for Base Hoist

| Ref No. | Description              | Part No. | Qty | Ref No. | Description      | Part No. | Qty |
|---------|--------------------------|----------|-----|---------|------------------|----------|-----|
| 1       | Main Frame Assembly      | LG3411B  | 1   | 13      | Pawl Shaft       | 445B     | 2   |
| 2       | Bushing                  | LM12     | 3   | 14      | Pawl             | 241B     | 2   |
| 3       | Pin, 1/8 X .88, Type G   | H5230-30 | 2   | 15      | Pawl Spring      | 23L2     | 1   |
| 4       | Pin, 3/16 X 1.00, Type B | H5230-31 | 1   | 16      | Free-Wheel Lever | 279B     | 1   |
| 5       | Pin, 1/4 X 2.50          | H5242    | 1   | 17      | Strap Drum       | 3470B    | 1   |
| 6       | Strap Roller             | 3427     | 1   | 18      | Return Spring    | 23L1     | 2   |
| 7       | Retaining Ring           | H5596    | 4   | 19      | Reversing Lever  | 47B      | 1   |
| 8       | Drum Shaft               | 472B     | 1   | 20      | Handle Lock      | 51       | 1   |
| 9       | Pin, 1/8 X 1.25          | 73-1     | 1   | 21      | Reversing Spring | 42       | 1   |
| 10      | Pin, 1/8 X 1.00          | H5251    | 1   | 22      | U-Frame Assembly | 446B     | 1   |
| 11      | Winding Wheel Assembly   | 32       | 1   | 23      | Name Plate Kit   | 676L1K   | 1   |
| 12      | Drum Shaft Assembly      | LG107B   | 1   | 24      | Drive Screw      | H2861P   | 2   |