

Paint Scrapers

Paint Scrapers can be used for most surface preparations. Use them to remove paint or varnish from furniture, molding, cornices, wooden sashes, etc.

PLASTIC SCRAPER, SINGLE-EDGE

Red Devil® Traditional single-edge steel blade with heavy-duty plastic handle. Use to remove paint or varnish from furniture, molding, cornices, wooden sashes, etc. Heavy-duty plastic handle. Steel blade can be resharpened.

3010 - 1" (2.6 cm) Blade
Use Replacement Blade No. 3061



PLASTIC SCRAPER, DOUBLE-EDGE

Red Devil® Traditional double-edge steel blade with heavy-duty plastic handle. Use to remove paint or varnish from furniture, molding, cornices, wooden sashes, etc. Heavy-duty plastic handle. Steel blade can be resharpened.

3040 - 1 1/2" (3.8 cm) Blade
Use Replacement Blade No. 3062
3050 - 2 1/2" (6.4 cm) Blade
Use Replacement Blade No. 3063



REPLACEMENT BLADES

3061 - 1" (2.6 cm) Single-edge
2 Blades per Package



3062 - 1 1/2" (3.8 cm) Double-edge
2 Blades per Package

3063 - 2 1/2" (6.4 cm) Double-edge
2 Blades per Package

