



**9 mm UTILITY KNIFE,  
AUTO-LOCK**

Perfect for cutting and trimming projects in the workplace and at home. 9 mm breakaway blade locks itself into position for safety.

3211  
Use Replacement Blade No. 3254



**9 mm UTILITY KNIFE,  
BREAKAWAY BLADE**

Perfect for cutting and trimming projects in the workplace and at home. Positive-lock, pull-back button retains blade tightly in cutting position and allows blade to retract safely into handle when not in use.

3210  
Use Replacement Blade No. 3254



**RAZOR KNIFE**

Heavy-duty, solvent resistant polypropylene handle molded right onto head. Use to trim wallcovering and for hundreds of home cutting projects. Uses a standard single-edge razor blade.

3231 - With 5 Blades  
Use Replacement Blade No's. 3270, 3271, 3272, or 3275



**BOX CUTTER**

A simple sliding action exposes tip of razor edge for most do-it-yourself cutting projects. Cuts corrugated cartons, cardboard, paper, wallcovering, etc. All-metal fabrication. Uses a standard single-edge razor blade.

3220 - Box of 12  
3221 - Individually Carded  
Use Replacement Blade No's. 3270, 3271, 3272, or 3275

