



Product Family
AirSoft Multiple-Use Earplug

Advanced air pocket design, optimized for comfort







[Learn more about our products at howardleight.com](http://howardleight.com)

>

[Learn more about hearing conservation at hearforever.org](http://hearforever.org) >



Product Numbers & Ordering Information

	Product Numbers	Details
	AS-30R	AirSoft - red polycord NRR 27 Canada Class A(L)
	DPAS-30R	AirSoft - red polycord NRR 27 Canada Class A(L)
	AS-1	AirSoft - uncorded NRR 27 Canada Class A(L)
	DPAS-1	AirSoft - uncorded NRR 27 Canada Class A(L)
	AS-30W	AirSoft - white nylon cord NRR 27 Canada Class A(L)
	DPAS-30W	AirSoft - white nylon cord NRR 27 Canada Class A(L)

Overview

Key Features

AirSoft Multiple-Use Earplug

- Advanced air pocket design features internal noise-blocking fins
- Four-flange profile creates better seal in the ear canal
- Less pressure in the ear canal eliminates that “plugged up” feeling
- Rounded flanges, tapered shape fits better in the ear canal
- Firm stem facilitates easy insertion and removal
- Outstanding noise-blocking protection

Recommended Industries/Use

- Agriculture
- Chemical
- Construction
- Food Services
- Forestry
- Government
- Law Enforcement
- Manufacturing
- Medical
- Military
- Mining
- Municipal Services
- Oil and Gas
- Pharmaceutical
- Steel and Metals
- Transportation
- Utilities
- Welding
- Nuclear

Hazards

- Noise

Regulations

- 29 CFR 1910.95 - OSHA Occupational Noise Exposure (US)
- ANSI S3.19-1974 - Attenuation Test Protocol (US)
- Part II, (R.S.C. 1985, c. L-2) - Occupational Noise Standard (CAN)
- Z94.2-1994 - Attenuation Test Protocol (CAN)
- 2003/10/EC - EU Hearing Directive
- 89/686/EEC - European Directive/PPE
- Category II - EC Category PPE
- EN 352-2:1993 - EU Standards
- NOHSC: 1007 (2000) - National Standard for Occupational Noise (AUS/NZ)
- AS/NZS 1270:2002 - Attenuation Test Protocol (AUS/NZ)
- NR 15 - Security and Health of Work, Annexes 1 and 2, n°3.214/1978 - Occupational Noise Regulations (BR)
- ANSI S12.6/1997 - Method B - Attenuation Test Protocol (BR)
- 9001:2008 - ISO

Historical Brand

Howard Leight

Warranty Information

There is a one year guarantee against defects in material and workmanship. The guarantee does not cover damage caused by misuse, abuse or unauthorized modifications.

Specifications

Color

- Blue

Shape

- 4 Flange

Material

- TPE

Packaging Options

- Polybag, Reusable Case

Cord Options

- Uncorded, Red Polycord, White Nylon Cord

NRR

- 27

Canada Class

- A

SNR

- 30

SLC80

- 26 dB / Class 5

EU Certifications

- European Directives – 89/686/EEC
- EC Category PPE – Category II
- Standards – EN 352-2:1993
- EC Certification Number – EC152
- EC Attestation Number – 152
- Laboratory – INSPEC

AUSNZ Standards


- Standardsmark License #1579

Certifications

 **CE Certificate - AirSoft**

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Secured/Hearing_Protection/Earplugs/20031/1033.aspx

CE Certificate - AirSoft

 **Instruction Manual - Airsoft (global)**

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Secured/Hearing_Protection/Earplugs/41907/1033.aspx

Click link above to download the user instructions for Airsoft.

Literature & Documents

Earplug Instruction Poster - EN

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection/Earplugs/19799/1033.aspx

Earplug Instruction Poster - ES

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection/Earplugs/19802/1033.aspx

Earplug Instruction Poster - FR

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection/Earplugs/19800/1033.aspx

Training & Proper Use

1. While holding the stem, reach a hand over your head and gently pull top of your ear up and back.
2. Insert the earplug so all flanges are well inside your ear canal.
3. If properly fitted, the tip of the earplug stem may be visible to someone looking at you from the front.
4. Proper Fit – If either or both earplugs do not seem to be fitted properly, remove the earplug and reinsert.
5. Removal – Gently twist earplug while slowly pulling in an outward motion for removal.
6. Acoustical Check – In a noisy environment, with earplugs inserted, cup your hands over your ears and release. Earplugs should block enough noise so that covering your ears with your hands should not result in a significant noise difference.

Additional Information

CARE + MAINTENANCE

- INSPECT - Prior to fitting, examine your earplugs for dirt, damage, deformation or extreme hardness. Discard immediately if compromised.
- CLEAN - Wash Multiple-Use earplugs with mild soap and warm water only. Pat dry with a towel and store in a case when not in use. Do not treat with any other substances, as the earplug may degrade and compromise use.
- HYGIENE - With proper maintenance, Multiple-Use earplugs can last for 2-4 weeks.

RELATED PRODUCTS