




1/2" DRIVE DEEP IMPACT SOCKETS - 8 POINT



- ▶ Radius-corner socket design
- ▶ Engages flats for better grip
- ▶ Improves the ability to turn worn or rounded fasteners



- ▶ Proto® 8 Point Impact Sockets are ideal for use on stubborn or damaged fasteners, and also on fasteners made from soft materials.
- ▶ Drive end chamfer and four detents help provide quick positive engagement with drive tool on any of the socket drive walls.
- ▶ Tight tolerances for snug fit on fastener.
- ▶ Large clearance holes, concentric opening and nut end chamfer make it easy to position socket on fasteners.
- ▶ Made from high-strength steel to help minimize wall thickness and provide access to fasteners in recesses and where nuts and bolts protrude.
- ▶ Impact sockets are used wherever powered drive tools are used to install or remove fasteners.
- ▶ Impact sockets are designed to withstand higher torque and force associated with impact tools in repetitive application.
- ▶ Extra length provides easy access to fasteners in recesses or where nuts and bolts protrude.
- ▶ Socket size stamped on tool for easy identification.
- ▶ Side locking hole.

| INCH | 8 | Nut End Outside Diameter (in) (B) | Drive End Outside Diameter (in) (C) | Nut Depth (in) (D) | Bolt Clearance Depth (in) (E) | Overall Length (in) (L) | Weight (lbs) |
|-------|---------------|-----------------------------------|-------------------------------------|--------------------|-------------------------------|-------------------------|--------------|
| 3/8 | J7312S | 3/4 | 7/8 | 11/32 | 2-19/32 | 3-1/4 | 0.37 |
| 7/16 | J7314S | 27/32 | 15/16 | 3/8 | 2-19/32 | 3-1/4 | 0.44 |
| 1/2 | J7316S | 51/16 | 15/16 | 7/16 | 2-19/32 | 3-1/4 | 0.43 |
| 9/16 | J7318S | 1-1/32 | 1-1/32 | 1/2 | 2-19/32 | 3-1/4 | 0.54 |
| 5/8 | J7320S | 1-1/8 | 1-1/8 | 1/2 | 2-19/32 | 3-1/4 | 0.63 |
| 11/16 | J7322S | 1-3/16 | 1-3/16 | 1-5/32 | 2-19/32 | 3-1/4 | 0.61 |
| 3/4 | J7324S | 1-5/16 | 1-5/16 | 1-5/32 | 2-19/32 | 3-1/4 | 0.76 |
| 13/16 | J7326S | 1-3/8 | 1-3/8 | 1-5/32 | 2-19/32 | 3-1/4 | 0.83 |
| 7/8 | J7328S | 1-1/2 | 1-1/2 | 1-13/32 | 2-27/32 | 3-1/2 | 1.10 |
| 15/16 | J7330S | 1-39/64 | 1-39/64 | 1-13/32 | 2-27/32 | 3-1/2 | 1.24 |
| 1 | J7332S | 1-11/16 | 1-11/16 | 1-13/32 | 2-27/32 | 3-1/2 | 1.54 |

ASME B107.2

THIN WALL IMPACT SOCKETS

When you need to fit an impact socket on a tightly spaced fastener, don't reach for a thin wall hand socket.

The correct tool is a thin wall impact socket, made from the same metal as standard impact sockets, available in both fractional and metric sizes.

The thinner wall helps to fit over the fastener in tight situations whereas the correct steel alloy will keep you safe and your tool running correctly.



Made from the same steel alloy as standard impact sockets, but thinner.